

## Cross Hatch Cutter

The Cross test is used to access adhesion of paint coating. This cutter having single cutting blades. Test is carried out by performing crossed cuts at right angle. After clear with adhesive type or brush.

### Result can classified with reference to a standard

- 1 mm model - 11 blades ( coating up to 60 Microns )
- 2 mm model - 6 blades ( coating 60-120 Microns )
- 3 mm model - 5 blades ( coating 120-250 Microns )
- As per ASTM D 3002, 3359 & IS Standards.

	IS Standard		ASTMD Standard
Ref.: 114 / 1	1 mm	Ref 114 / 4	1 mm
Ref.: 114 / 2	2 mm	Ref 114 / 5	2 mm
Ref.: 114 / 3	3 mm	Ref 114 / 6	3 mm

Ref.: 114 / 7 Adhesive Tape ( ISO Certified )

Ref.: 114 / 8 Scotch Tape ( USA make )



ASTM STANDARD

IS STANDARD