



Adhesion / Wet Film Gauge

Wet Film Calling Card Thickness Gauge

Simple operating Stainless Steel comb with tooth lengths varying by equal amount is applied perpendicular to the wet film and thickness can read on the last tooth made contact with the wet coating.

As per ASTM D 4414, BS 3900.

- Ref.: 166 / 100 Range : 5 - 100 Microns
- Ref.: 166 / 500 Range : 25 - 500 Microns
- Ref.: 166 / 2000 Range : 25 - 2000 Microns

