

Colour Scanner (Portable) Muse

Imported Variable Inc. USA Make

The Colour muse works with an app on your Mobile to scan and match colours.

All you need to do is place the colour muse on the surface and press scan on the app.

The app is free and will show a list of the best color matches and the brand of paint it comes in. However it can match paint, Tiles, Carpet, Clothing, shoes.

- For painters, designers, and colour professionals, Colour Muse is the digital resource that revolutionizes how the world interacts with colour.
- A compact, powerful tool, Color Muse is designed to fit in your pocket or bag.

Features :

- i) Android or IOS operating system.
- ii) Scan a color for RGB, HSB or LCH Values.
- iii) Color Compare ΔE value
- iv) View & Export facility via test message, email or media.



Colour Matching Cabinet

Colour looks different under different lighting condition. Colour Matching Cabinet reduces the difference between neutral view and standard light source.

Useful in paint, automobile ink, Printing, Packaging and textile Industry. Where to maintain Colour Consistency and quality.

Specifications of illuminations:

- | | |
|-------------------------------|---------|
| • Daylight D 65 (6500 K) | - 1 No. |
| • Incandescent 2856 K (A) | - 1 No. |
| • D 50 (5000 k) (CDL) | - 1 No. |
| • Ultraviolet (UV) | - 1 No. |
| • TL 84 | - 1 No. |
| • Coolwhite fluorescent (CWL) | - 1 No. |

Size : 28" X 20" X 16"

Standard : ASTM D 1729, ISO 3664

Ref. : 945

